

**Useful Code Blocks**

program start

set A HI → This would turn in on

set A LO → This would turn it off

do 10 times

do forever

loop

wait 1 seconds

**Wiring**

This buzzer is controlled by D


It could be controlled by A, B C or D

Crumble Maker must be powered for the buzzer to work when unconnected to the PC

### Hints

The buzzer can be powered from either side.  
 These can be purchased from 4Tronix

# Crumble Maker Cards Buzzer



This work is licensed under the Creative Commons Attribution-NonCommercial 3.0 Unported License. To view a copy of this license, visit <http://creativecommons.org/licenses/by-nc/3.0/> or send a letter to Creative Commons, 444 Castro Street, Suite 900, Mountain View, California, 94041, USA.